Traktor Pro setup 'faderfox DL3 V01.tsi' FX parameter 1 FX parameter 2 FX parameter 3 Dry / Wet FX1 amount FX2 amount FX3 amount FX Select (advanced) FX1 Select (chained) FX2 Select (chained) FX3 Select (chained) FX reset (advanced) FX button 1 (advanced) FX button 2 (advanced) Switch on/off FX (advanced) FX3 on/off (chained) FX1 on/off (chained) FX2 on/off (chained) Select FX1-slot Select FX2-slot Select FX3-slot Select FX4-slot ect preset 2 for selected slot press again to toggle advanced/chained mode Select preset 3 for selected slot Select preset 1 for selected slot press again to toggle advanced/chained mod press again to toggle advanced/chained mod press again to toggle advanced/chained mod (indicated by green led 3, (indicated by green led 1, (indicated by green led 2, blinks during chained mode) blinks during chained mode) blinks during chained mode) Activate/deactivate filter (indicated by green led) Effect settings snapshot Activate/deactivate key lock (indicated by green led) (Press both filter buttons to get traktors monitor state) Load selected track into deck Favorites select left = previous , right = next (Press both load buttons and hold for about 1 second to enter/leave system mode)

Filter frequency

Key control

Loop move left button: backward right button: forward

loop move size left button: move size = fine right button: move size = loop

Sync (indicated by green sync led)

> Assign deck A to controllers left side (indicated by red A led)

Play / pause (indicated by green play led)

Assign deck C to controllers left side (indicated by red C led)

Sys led lit = system mode is active blinks = controller isn't recognized

> Svnc (indicated by green sync led)

> > Assign deck B to controllers right side (indicated by red B led)

Play / pause (indicated by green play led)

faderfox

Assign deck D to controllers right side (indicated by red D led) (indicated by green led 4, blinks during chained mode)

Hold preset button to select presets by the green buttons and select FX types by the pots (FX types will be stored in device by releasing preset button)

Browse thru track list Push to reset effect LFO

Browse thru tree Push to expand/collapse tree

Loop size Press both buttons to reset size to 1 (indicated by green leds above)

left button: set loop-in-point right button: set loop-out-point (indicated by red led between)

Activate/deactivate loop (indicated by red led above)

Activate/deactivate loop (indicated by red led above)

Select cue points left button: previous cue point right button: next cue point

> Assign the deck to FX slot 1 and 2

Cue play / Cue pause (Cup)

Assign the deck to FX slot 3 and 4